

Hampton Bay Universal Remote Control Codes by

<http://hamptonbayshop.com>

Television Code:-

Admiral 005
Amtron 064
Akai 002
Anam National 038
AOC 011, 019, 027, 088
Bell & Howell 005
Candle 011, 027, 033
Citizen 011, 027, 033, 064
Colortyme 011, 027, 084
Concerto 011, 027
Contec/Cony 036, 037, 040, 042, 064
Craig 064
Curtis Mathes 000, 011, 015, 027
CXC 064
Daewoo 011, 019, 027
Daytron 011, 027
Dimensia 000
Electrohome 006, 011, 014, 027, 038, 061, 068
Emerson 011, 026, 027, 028, 029, 030, 031, 032, 037, 042, 053, 064, 065, 067, 075, 076, 079
Envision 011, 027
Fisher 017, 021, 039, 041
Funai 064
GE 000, 008, 009, 011, 012, 027, 038, 068, 086, 089, 091
Goldstar 003, 004, 006, 011, 019, 027, 037, 050
Hallmark 011, 027
Hitachi 009, 011, 027, 036, 037, 040, 047, 048, 063, 080
Infinity 013
JBL 013
Jensen 011, 027
JVC 012, 024, 036, 037, 040, 048, 051, 074
Kawasho 002, 011, 027
Kenwood 006, 011, 014, 027
Kloss Novabeam 035, 043
KTV 078
Loewe 013
Luxman 011, 027
LXI 000, 013, 018, 021, 023, 054
Magnavox 006, 007, 010, 011, 013, 016, 027, 033, 035, 043, 066, 087, 089
Marantz 013
Marantz 011, 013, 027, 069
Memorex 005
MGA 006, 011, 014, 019, 022, 027, 041, 056, 061, 068
Mitsubishi 006, 011, 014, 019, 022, 027, 041, 055, 056, 061, 068
MTC 011, 019, 027
Multivision 081
NAD 018, 023
NEC 011, 014, 019, 027, 038
Panasonic 012, 013, 038, 086
Penny 000, 008, 011, 019, 027, 068, 086
Philco 006, 007, 010, 011, 013, 016, 019, 027, 033, 035, 037, 038, 043, 087, 089
Philips 006, 007, 010, 011, 013, 016, 033, 035, 037, 038, 043, 066, 073
Pioneer 011, 027, 045, 062, 093
Portland 011, 019, 027
ProScan 000
Proton 011, 027, 037, 072
Quasar 012, 038, 092
Radio Shack 000, 021, 025, 036, 037, 059, 064
RCA 000, 006, 011, 019, 027, 034, 038, 044, 046, 088

Hampton Bay Universal Remote Control Codes by

<http://hamptonbayshop.com>

Realistic 021

Sampo 011, 027
Samsung 006, 011, 014, 015, 019, 027, 036, 037, 077
Sanyo 017, 021, 039, 056, 057, 058
Scott 028, 037, 064
Sears 000, 006, 011, 014, 017, 018, 021, 023, 027, 039, 040, 041, 051, 071, 083
Sharp 011, 020, 025, 027, 037, 052, 053, 059, 060
Signature 005, 094
Sony 002
Soundesign 011, 027, 033
Sylvania 006, 007, 010, 011, 013, 016, 027, 033, 035, 043, 049, 066, 087, 089
Symphonic 064, 076
Tatung 038
Technics 012
Techwood 011, 027
Teknika 011, 019, 027, 033, 037, 040, 066
Telecaption 090
TMK 011, 027
Toshiba 018, 021, 023, 071, 085, 090
Universal 008, 009
Victor 051
Vidtech 019, 027
Wards 000, 005, 006, 007, 008, 009, 010, 011, 013, 019, 025, 027, 028, 035, 043, 059, 066, 076, 082, 089
Yamaha 006, 014, 019, 027
Zenith 001

VCRs:-

Admiral 006
Aiwa 015
Akai 003, 017, 022, 023, 063, 066
Audio Dynamics 014, 016
Bell&Howell 002
Broksonic 010
Candle 007, 009, 013, 044, 045, 046, 052
Canon 008, 053
Capehart 001
Citizen 007, 009, 013, 044, 045, 046, 052
Colortyme 014
Craig 007, 012
Curtis-Mathes 000, 007, 008, 014, 015, 044, 046, 053, 064, 067
Daewoo 013, 045, 052
DBX 014, 016
Dimensia 000
Dynatech 015
Electrohome 027
Emerson 008, 009, 010, 013, 015, 020, 023, 027, 034, 041, 042, 047, 057, 062, 065, 067, 068, 070
Fisher 002, 012, 018, 019, 043, 048, 058
Funai 015
GE 000, 007, 008, 032, 053
Goldstar 009, 014, 046, 060
Harman Kardon 014
Hitachi 005, 015, 035, 036
Instant Replay 008
JCL 008
JC Penny 002, 005, 007, 008, 014, 016, 030, 035, 051, 053
JVC 002, 014, 016, 030, 046
Kenwood 002, 014, 016, 030, 044, 046
Lloyd 015
Logik 031

Hampton Bay Universal Remote Control Codes by

<http://hamptonbayshop.com>

Magnavox 008, 029, 053, 056
Marantz 002, 008, 014, 016, 029, 030, 044, 046, 061
Marta 009
MEI 008
Memorex 008, 009, 012, 015
MGA 004, 027
Midland 032
Minolta 005, 035
Mitsubishi 004, 005, 027, 035, 040
Montgomery Ward 006
MTC 007, 015
Multitech 007, 015, 031, 032
NEC 002, 014, 016, 030, 044, 046, 059, 061, 064
Panasonic 008, 053
Pentax 005, 035, 044
Pentax Research 046
Philco 008, 029, 053, 056
Philips 008, 029
Pioneer 005, 016, 033, 050
Portland 044, 045, 052
ProScan 000
Quartz 002
Quasar 008, 053
RCA 000, 005, 007, 008, 028, 035, 037, 054, 069
Radio Shack & Realistic 002, 006, 008, 009, 012, 015, 019, 035, 043, 053
Samsung 007, 013, 022, 032, 042
Sansui 016, 071
Sanyo 002, 012
Scott 004, 013, 041, 049, 068
Sears 002, 005, 009, 012, 018, 019, 035, 043, 048
Sharp 006, 024, 027, 039, 045
Shintom 017, 026, 031, 035
Signature 015
Sony 017, 026, 038
Sylvania 008, 015, 029, 053, 056
Symphonic 015
Tandy 002, 015
Tashiko 009
Tatung 030
Teac 015, 030, 069
Technics 008
Teknika 008, 009, 015, 021
Toshiba 005, 013, 019, 048, 049
Totevision 007, 009
TMK 067
Unitech 007
Vector Research 014, 016, 044
Victor 016
Video Concepts 014, 016, 044
Videosonic 007
Wards 005, 006, 007, 008, 009, 012, 013, 015, 025, 027, 031, 035
Yamaha 002, 014, 016, 030, 046
Zenith 011, 017, 026

Cable Boxes:-

ABC 022, 046, 053, 054
Anvision 007, 008
Cablestar 007, 008

Hampton Bay Universal Remote Control Codes by

<http://hamptonbayshop.com>

Diamond 056
Eagle 007, 008
Eastern Int 002
General Instrument 046
GI 400 004, 005, 015, 023, 024, 025, 030, 036
Hamlin 003, 012, 013, 034, 048
Hitachi 037, 043, 046
Jerrold 004, 005, 015, 023, 024, 025, 030, 036, 045, 046, 047
Macom 037, 043
Magnavox 007, 008, 019, 021, 026, 028, 029, 032, 033, 040, 041
NSC 009
Oak 001, 016, 038
Oak Sigma 016
Panasonic 003, 027, 039
Philips 007, 008, 009, 021, 026, 028, 029, 032, 033, 040, 041
Pioneer 018, 020, 044
RCA 000, 027
Randtek 007, 008
Regal 003, 012, 013
Regency 002, 033
Samsung 044
Sci. Atlanta 003, 022, 025
Signature 046
Sprucer 027
Starcom 046
Stargate 2000 058
Sylvania 015, 059
Teknika 006
Texscan 010, 011, 059
Tocom 017, 021, 049, 050, 055
Unika 031, 032, 041
Universal 051, 052
Viewstar 007, 008, 019, 021, 026, 028, 029, 032, 033, 040, 041
Warner Amex 044